Console moulding switch panel assembly-front



Before repairing any electrical parts, starting switch power mode must be set to OFF state, and all electrical loads must be OFF, unless otherwise specified in the operation procedure. If any tool or equipment is easy to contact any exposed live electrical terminal, disconnect the negative battery cable, too. Any violation of these safety instructions may result in personal injuries or damages to the vehicle and its components.

NOTE


- There might be some differences on illustrations of this program, and you are advised to the vehicle configuration, but the basic information is always correct.
- There might be some parts that are not displayed on the illustration. That will help display the main parts more clearly.

Removal




Be sure to use a tool made of plastic or similar materials when removing the switch.

1. Remove the console moulding switch panel assembly-front.







2. Disconnect the power socket and multimedia USB harness connector.



3. Disconnect the on-board wireless charger harness connector (if equipped).



- 4. Remove the front USB interface cover plate. See: Front USB interface cover panel
- 5. Remove the power source socket-front. See: Power source socket-front
- 6. Remove the four mounting screws between the console moulding switch panel assemblyfront and the on-board wireless charger (if equipped).



Installation

- 1. Install the four mounting screws between the console moulding switch panel assemblyfront and the on-board wireless charger (if equipped).
- 2. Install the power source socket-front. See: Power source socket-front
- 3. Install the front USB interface cover plate. See: Front USB interface cover panel
- 4. Connect the on-board wireless charger harness connector (if equipped).
- 5. Connect the backup power source and multimedia USB harness connector.
- 6. Install the console moulding switch panel assembly-front.

When installing the interior trim, please confirm that the interior trim claw is aligned with the mounting position, and then press the interior trim gently to prevent damage to the interior trim jaw.